

SWAG Portaband Table V2.0 Installation Instructions



1) Install bolt on side legs:

Attach the bolt on side legs using the supplied 5/16" nuts and bolts.



(2) Remove Factory Foot Guard:

Remove the factory blade guard on your Dewalt DW328 Portaband saw.

(3) Tab The Bearing Block

Using the provided 10x24 tap, tap the back side of the bearing block ~.500" deep by using either a portable drill as shown or a tap wrench, take your time and use cutting fluid or grease to cut new threads in the aluminum block.



4) Install Blade Guard:

Install the blade guard used the original two screws you removed from saw as well as the provided 10X24X.50" fasteners on the back side as shown below.



5) Final Install:

Install the Dewalt DW328 saw into the SWAG V2.0 Portaband table and tighten using the two provided red thumb knobs. Please note it may be necessary to use the provided 5/16" washers to prevent the red thumb knob from protruding through the top working surface of the table.

